

APRS on HF By

Julie VK3FOWL and Joe VK3YSP

APRS at Hahndorf Oval



APRS Network



- RF User
- Portable User
- Mobile User
- Weather Station
- Fill-In Digipeater
- Wide Digipeater
- IGate
- APRS Database
- Internet User

Automatic Packet Reporting System

- For broadcasting location, telemetry data, text
- Over both RF and Internet networks
- Nodes are identified by Callsign-SSID format
- Messages are unnumbered AX.25 datagrams
- Each node can store and forward messages
- The message "Path" contains a routing list
- Digipeaters modify Path to avert "ping-pong"

APRS Secondary Station ID (SSID)

- -0 (No SSID) Home Station
- -1 Digipeater, or Home Station running a Fill-In Digi,
- -2 Digipeater [#2] on 70CM
- -3 Digipeater [#3]
- -4 HF to VHF Gateway
- -5 IGate (Dedicated system, not home station)
- -6 Operation via Satellite
- -7 Kenwood D7 Handheld
- -8 Secondary Mobile usage (also Maritime vessels) (VHF / UHF)
- -9 Mobiles (VHF / UHF)
- -10 Operation via Internet Only (No RF capability)
- -11 is for APRStouch-tone users (also high altitude balloons)
- -12 Portable Units such as Laptops, Camp Sites etc
- -13
- -14 Interstate Truckers
- -15 Operation via HF

APRS Paths

- Path is a routing list: VK3ABC-1, VK3XYZ-1, etc
- Can use callsign aliases for special nodes: WIDE1-1, WIDE2-1
- The SSID of aliases sets the number of hops allowed
- The path is modified by each digipeater
- The SSID is decremented in each hop, but -0 is omitted.
- An asterisk (*) signifies when a callsign or alias was used
- Example:
 - WIDE1-1, WIDE2-2 (Original path)
 - <callsign1>*, WIDE2-2 (First hop)
 - <callsign1>, <callsign2>, WIDE2-1* (Second hop)
 - <callsign1>, <callsign2>, <callsign3>* (Third hop)

APRS Rules for HF

- No Digipeating on HF!
- Most receiving Gateways will route to APRS-IS
- So, Path = WIDE1-1 is sufficient
- Use 300 Baud, 200Hz FSK, 1600Hz/1800Hz
- For SSB must be spot on frequency
- LSB & USB both work because AX.25 is NRZI
- Avoid any ALC action on TX to limit distortion
- Beacon time ≥ 10 minutes: Permits up to 70 users
- Good luck Because APRS has no ACK or FEC

APRS Frequencies and Gateways

40m 7048.600kHz LSB

VK2IO-4 Sydney Primary Net Station (also 7.047.17 LSB)

VK7HSE-4 Kingston Secondary Net Station

30m 10147.600kHz USB

VK1IAN-1 Canberra RX Only

VK2ACW-1 Orange

VK2HL-1 Sydney Part Time RX Only

VK2IO-4 Sydney Offline

VK2OL-5 Sydney Full Time RX Only

VK2ZSZ-4 Queanbeyan Full Time RX Only

VK2ZZM-5 Sydney Full Time RX Only

VK3MY-4 Melbourne Primary Net station

VK4AB-4 Ipswich Full Time

VK4DMI-4 Pine Rivers Secondary Net station

VK4MQ-5 Toowoomba Full Time RX Only

VK4RM-4 Mackay Full Time
VK4UN-4 Tewantin Full Time

VK5RR-4 Waikerie

VK6LD-4 Perth Full Time
VK7ZRO-4 Bothwell Full Time


VK8KMD-10 Alice Springs

ZL3GR-4 Tauranga RX Only

20m 14103.00kHz LSB

VK2IO-4 Sydney Offline

APRS TNC With GPS



T3 Mini TNC Pin Assignments

A1-A4 Analog inputs 1-4 (max voltage 4xVdd)

1W Dallas 1-Wire data bus

SQL Squelch input

AUX Auxiliary I/O pin

GND Ground

RST Reset (active low)

B-RX Serial port B input

B-TX Serial port B output

A-RX Serial port A input

A-TX Serial port A output

CFG Configuration select

AOUT Audio output (to radio)

AIN Audio input (from radio)

GRN Green LED output for external LED


RED Red LED output for external LED

PTT Push-to-talk (open collector)


5V Regulator output or Vdd input, 5v max, 2.8v min

VIN Unregulated supply voltage, 6v to 28v

GP1-GP12 General purpose digital input/output pins




Pictorial Schematic Diagram



APRS TNC Assembly

- Hammond H9004 ABS Enclosure
- Transformers and regulator glued to base
- Sleeved grommet for CAT-5 cable




APRS TNC Enclosure

- APRS dongle needs a clear view of the sky
- Starts transmitting when 3D GPS fix is valid



Codan 2110 Manpack Radio Cable







TNC Configuration Tool

OpenTracker Configuration	X
Profile 1 Profile 2 Firmware Build 57130	_,
Callsign VK3YSP-15	
N	
Counter Power Control 33 TX Delay (mSec) HT PTT Enable Don't transmit if supply < 0.00 Volts Active Low Invert Carrier Detect Software DCD Adebounce (mSec) delay (seconds)	
● Metric C English Copy from Profile 2 Save to File Load from File Write Quit	

APRS Display



APRS Info



Links

- http://www.sarcnet.org/projects.html
- http://www.aprs.org
- http://www.aprs.net.au
- http://info.aprs.net
- http://aprs.fi
- https://www.argentdata.com